## Ep 7

step 1 add 4 pcs,2 pt switches,2 pt routers.

step 2 connect the pc and switches by fastethernet.0.0 using copper straight wire.

and connect same for switch and router, then connect to 2 routers using DTE with serial 2/0.

step 3 add label 192.168.0.0 betwn switch and router, add label 192.168.2.0 betwn other switch and router and betwn routers add label 192.168.1.0

step 4 select pcs and goto desktop ip config select type ip 192.168.0.2 and 192.168.0.1 other pc 192.168.0.3 and 192.168.0.1.

similarly 192.168.2.2 and 192.168.2.1 and 192.168.2.3 and 192.168.2.1.

step 5 go to router add 192.168.0.1 (fastethernet) and add 192.168.1.1 (serial 2/0) and for other router add 192.168.2.1

and 192.168.1.2 (serial)

step5 select router add RIP add 192.168.0.0 ,192.168.1.0,192.168.3.0 step 6 send packets .

